LETTO ADJUSTABLE BED

USER MANUAL

BRING COMFORT TO YOUR ROOM

Letto™

ITALIAN DESIGNED

READ THIS INSTRUCTION MANUAL AND OBSERVE SAFETY INSTRUCTIONS

Warnings

Please read this instruction manual carefully prior to using and assembling the Letto Adjustable Bed ("the bed"). If the bed changes ownership, this instruction manual must be supplied to the new owner.

Ensure all electrical components, including motors and controls, are correctly connected and in good working condition. Keep electrical cords away from water sources and do not overload electrical outlets.

Do not exceed the maximum weight limits. The static weight limit per bed frame is 300 kg. The maximum user weight while operating or adjusting the bed is 150 kg. Exceeding these limits may damage the bed, cause injury, and will void the warranty. Distribute body weight evenly across the bed surface at all times. Do not place your full body weight on the head or foot sections of the bed when repositioning, entering, or exiting the bed.

Adjust the bed slowly and with care. Sudden or rapid movements may cause loss of balance or entrapment between moving parts, resulting in injury. Keep hands, fingers, and all body parts clear of moving mechanisms while the bed is in operation.

Children, elderly persons, and any individuals who may have limited physical, cognitive, or sensory ability must not operate the bed without appropriate adult supervision, as they may not fully understand the potential risks associated with moving parts. Do not allow any person or pet to be under the bed at any time.

If you have any pre-existing or current medical condition, including but not limited to back, circulatory, or mobility issues, consult a qualified healthcare professional before using the bed. Letto products are not medical, hospital, or chiropractic devices and are designed for residential use only.

Only use a compatible Letto mattress specifically designed for adjustable beds. Using an unsuitable mattress may restrict movement, overload the motors, and cause damage.

This bed is designed for residential use only and is not approved for healthcare use. The motors are not designed to operate continuously for more than two (2) minutes within any eighteen (18) minute period. Exceeding this operating limit may reduce the lifespan of the product and will void the warranty.

To make a warranty claim, any servicing or repairs required must be carried out using Letto original spare parts only. The Letto warranty does not cover damage caused by normal wear and tear, misuse, abuse, improper cleaning, failure to follow installation or operating instructions, transportation damage, or repairs carried out using non-authorised or non-standard parts, or by unauthorised service providers.

As outlined in our Warranty Statement, Letto provides a limited ten (10) year warranty. Full terms and conditions are available on our website at www.letto.com.au.

Assembly

1. Remove the bed from the carton and plastic bag.
2. Unfold the bed base upside down on the floor.
3. Remove and unpack all bed components.
4. Insert the safety pins.
5. Screw the six legs into the base. Note that by unscrewing each leg section, you can choose between three different heights.
6. Connect the power cord to the adapter (rectangular power box) and plug it into a nearby outlet. If you frequently experience power outages or often disconnect the bed from the power outlet, we highly recommend using two rechargeable 9V batteries, which can be inserted into the adapter.
7. Flip the bed base over onto its legs.
8. Attach the side and foot end mattress retainers.
9. Place the battery into the remote to operate the bed.



Components

1. Remote Control (2x AAA Battery Included)
2. Adaptor (2x 9V Rechargeable Batteries Not Included)
3. Power Cable
4. Safety Pins
6. Adjustable Legs
7. Mattress Retainers

Operation & Troubleshooting

One Touch Preset Positions - Press and Release*
TV watching TV while in bed
Lounge relax your body
Anti Snore prevent snoring
Zero Gravity helps with pain & pressure relief, blood circulation & breathing
Flat brings the bed back to a flat position

Memory Positions
In order to memorise new bed position, press and hold M1 or M2 button for 3 seconds or until you hear 3 beeps.

Massage Mode
a. Upper Body Massage (3 intensity levels)
b. Lower Body Massage (3 intensity levels)
c. Change Massage Mode (3 massage modes)
d. Massage Timer (10min, 20min, 30min)
e. Turn Off Massage

Lights
g. Remote Control Flash Light
f. Under Bed Light

***Preset Button Reset Instructions**
If a preset position changes, it is likely that the preset button was pressed and held, which reprograms the button. To restore the preset position, adjust the bed to your desired position, then press and hold the selected preset button for around 3 seconds or until you hear three beeps. The previous position will be overwritten and the new position will be saved.

Synchronize Both Bed Bases to One Remote
Pair one remote to both bed bases

Remote Control Paring
Press Back Up and Leg Up button together and then press Control Box Learn Button (also found on power lead), you will hear 3 beeps. Please note that each Remote Control comes already paired with each bed base.

Troubleshooting
Bed has lost power and functions

1. Re-pair the remote control with the bed using the Remote Control Pairing Instructions provided above.
2. The surge protection or the electrical outlet may be defective. Test the outlet by plugging in another working appliance.
3. Check batteries in wireless remote control. Replace with two new AAA batteries if necessary.
4. Ensure that the green light on the adapter (rectangular power box) is ON. If you frequently experience power outages or often disconnect the bed from the power outlet, we highly recommend using two rechargeable 9V batteries, which can be inserted into the adapter box.).

Contact us
support@letto.com.au
www.letto.com.au